

# Agilent Advantage Services Tips for Preventing Damage to 42841A and LCR Meter

Agilent Model 42841A and LCR Meter

#### Ensure proper grounding

- Always use the three-prong AC power cord supplied with the instrument.
- Proper grounding of the instrument will prevent a buildup of electrostatic charge which may be harmful to the instrument and the operator.
- Do not damage the earth-grounding protection by using an extension cable, power cable or autotransformer without a protective ground conductor.
- Check AC power quality and polarity; typical AC voltage required is 100 V, 120 V, 220 V  $\pm$ 10% or 240 V  $\pm$ 5%/ -10%. Typical expected grounding wire resistance is < 1  $\Omega$ , the voltage between neutral and ground line is < 1 V. Install uninterruptible power supply [UPS] if necessary.
- For more information, visit www.metrologyforum. tm.agilent.com/grounding.shtml.

## Check for proper temperature and humidity

- Keep unit in a clean and dry environment. Typical optimal operating temperature is 23 °C to -5 °C, always keep instrument ambient temperature at < 35 °C.</li>
- Ventilation holes and fans should be inspected and cleaned frequently.
- Keep working environment clean. Dust may cause ESD damages. Fuzz or dust may hinder the fan turning normally and the unit may fail to be powered adequately.



#### Follow electrostatic discharge precautions

- Electrostatic discharge (ESD) can damage or destroy electronic components. Whenever possible, conduct testing at a static-safe workstation. Keep electrostatic-generating materials at least one meter away from all components.
- For more information visit the Electrostatic Discharge Association **www.esda.org**.



### Connect LCR meter (4284A/4285A/ E4980A) properly to 42841A bias current source and follow operation procedures correctly

- Do not apply DC voltage or current to the unknown terminals. Doing so will damage KCR meter.
- Before measuring a capacitor, ensure it is fully discharged.
- Turn off power of 42841A and LCR meter when connecting or disconnecting them with others.
- Do not put device under test [DUT) outside of 42841A/B box while measuring.
- Enable and disable bias current by pressing DC Bias key on LCR meter front panel. Do not disconnect current by removing DUT or cables.
- Always disable bias current before removing DUT or disconnecting 42841A from LCR meter.
- Do not power off LCR meter or 42841A before disabling bias current.
- Use appropriate test fixtures and compensations to achieve accurate measurement. Occasional cleaning of the unknown terminals of LCR meter as well as the test fixtures is recommended for best results.
- Use Agilent Technologies specified memory cards. For example, 4284A use memory cards which contains 4284A specific data only. If other memory cards are used, it may be destroyed. Non 4284A specific data contained on the memory card is not guaranteed, data may be lost.
- Do not remove memory card while loading or storing data. Store memory card in memory card case for preventing contamination and ESD.



# Get the latest information about your product

- Check for updated service notes: www.agilent.com/find/servicenotes
- Subscribe to the Agilent e-mail updates: www.agilent.com/find/emailupdate
- For worldwide service locations visit: www.agilent.com/find/assist



Agilent Advantage Services is committed to your success throughout your equipment's lifetime. To keep you competitive, we continually invest in tools and processes that speed up calibration and repair and reduce your cost of ownership. You can also use Infoline Web Services to manage equipment and services more effectively. By sharing our measurement and service expertise, we help you create the products that change our world.

www.agilent.com/find/advantageservices

### **Order Information**

Contact an Agilent sales representative at www.agilent.com/find/assist

#### www.agilent.com

Product specifications and descriptions in this document subject to change without notice.

© Agilent Technologies, Inc. 2011 Printed in USA, May 18, 2011 5989-8784EN

